

Photodiode as current source

Student Group

| First Name | Surname | Matrikel Nr. |
|------------|---------|--------------|
| | | |
| | | |
| | | |

Table of Contents

Photo Diode as current source 2

Photo Diode as current source



Fig. 2: Inverting Op-Amp: Photo Diode BPW 34 S



Fig. 3: Inverting Op-Amp: Diagramms of BPW 34 S



Fig. 4: Inverting Op-Amp: Photo Diode as current source

$$U_{DD} = 10V, U_{SS} = -10V$$

We assume a good illuminated room of 300 lx, illuminated by a white LED. White light is a mixture of many wavelengths across the visible spectrum, roughly 380 to 780 nm. For a typical white LED, the spectrum usually comes from a blue LED chip with a peak around 450 nm, plus a broader phosphor emission that spreads across green, yellow, and red wavelengths. For an easier calculation, we take a mean value of 500 nm which is close to the peak value of the blue LED (in reality a greenish light) and 300 lx for the illumination. In figure 3 we can see that the sensitivity of the photo diode at 500 nm is only 30%. The maximum current (100%) at 300 lx is around 30 μ A. Now we can calculate the current we expect from the diode at 300 lx: Complete the arrows in the schematic of the circuit. Take the values for U_1, U_2, U_{OUT} from . Use these values to calculate the sum of the voltages at node N_{12} . Compare your result by measurement.

$$U_1 =$$

$$U_2 =$$

$$U_{OUT} =$$

