

Inverting Operational Amplifier

Student Group

| First Name | Surname | Matrikel Nr. |
|------------|---------|--------------|
| | | |
| | | |
| | | |

Table of Contents

| | |
|--|---|
| Inverting Operational Amplifier | 2 |
| Gain of Op-Amp | 2 |
| Investigation of inverting input | 3 |

Inverting Operational Amplifier

Gain of Op-Amp

Build the following circuit in [figure 1](#) with the power supply and a multimeter.



Fig. 1: Inverting Op-Amp

$U_{DD} = 10\text{ V}$, $U_{SS} = -10\text{ V}$, $R_1 = 10\text{ k}\Omega$

Calculate the necessary value for R_2 , so that the Output U_{OUT} is +5 V. Use the supply voltage of the operational amplifier for U_{IN} .

$U_{IN} =$

R_2

Investigation of inverting input



Fig. 2: Inverting Op-Amp: Investigate inverting input

$U_{DD} = 10\text{V}$, $U_{SS} = -10\text{V}$, $R_1 = 10\text{k}\Omega$

For U_{IN} , U_{OUT} , R_2 use the values from [figure 1](#).

Complete the arrows in the schematic of the circuit.

Determine the currents I_1 and I_2 indirectly through a voltage measurement.

Calculate the sum of the currents at node N_{12} .

$$I_{\text{1}} \approx I_{\text{2}}$$
$$I_{\text{2}} \approx I_{\text{N12}}$$
$$I_{\text{N12}} \approx I_{\text{2}}$$

- Virt masse messen
- r2 kurzschluss

From:

<https://wiki.mexle.org/> - MEXLE Wiki

Permanent link:

https://wiki.mexle.org/lab05_en/inverting_op-amp_basics_amplification?rev=1775057419

Last update: **2026/04/01 17:30**

