

Inverting Operational Amplifier

Student Group

First Name	Surname	Matrikel Nr.

Table of Contents

Inverting Operational Amplifier	2
Gain of Op-Amp	2
Investigation of inverting input	3

Inverting Operational Amplifier

Gain of Op-Amp

Build the following circuit in [figure 1](#) with the power supply and a multimeter.



Fig. 1: Inverting Op-Amp

$U_{DD} = 10\text{ V}$, $U_{SS} = -10\text{ V}$, $R_1 = 10\text{ k}\Omega$

Calculate the necessary value for R_2 , so that the Output U_{OUT} is +5 V. Use the supply voltage of the operational amplifier for U_{IN} .

$U_{IN} =$

$$R_2$$

Investigation of inverting input



Fig. 2: Inverting Op-Amp: Investigate inverting input

$$U_{DD} = 10V, U_{SS} = -10V, R_1 = 10k\Omega$$

Use the values from [figure 1](#) for U_{IN}, U_{OUT}, R_2 .

Complete the arrows in the schematic of the circuit.

Determine the the currents I_1 and I_2 indirectly through a voltage measurement.

Calculate the sum of the currents at node N_{12} .

$$U_1$$

$$U_2$$

$$I_{\text{1}} \approx I_{\text{2}}$$
$$I_{\text{2}} \approx I_{\text{N12}}$$
$$I_{\text{N12}} \approx I_{\text{2}}$$

- Virt masse messen
- r2 kurzschluss

From:

<https://wiki.mexle.org/> - MEXLE Wiki

Permanent link:

https://wiki.mexle.org/lab05_en/inverting_op-amp_basics_amplification?rev=1775057590

Last update: **2026/04/01 17:33**

