

# Block 16 - Ampère's Law and Magnetomotive Force (MMF)

## Student Group

First Name	Surname	Matrikel Nr.

## Table of Contents

- Block 16 - Ampère's Law and Magnetomotive Force (MMF)** ..... 2
- Learning objectives* ..... 2
- Preparation at Home* ..... 2
- 90-minute plan* ..... 2
- Conceptual overview* ..... 2
- Core content* ..... 2
- Generalization of the Magnetic Field Strength* ..... 2
  - Notice: ..... 3
  - Notice: ..... 4
- Common pitfalls* ..... 5
- Exercises* ..... 5
  - Worked examples ..... 5
- Embedded resources* ..... 5

# Block 16 - Ampère's Law and Magnetomotive Force (MMF)

## Learning objectives

After this 90-minute block, you can

- ...

## Preparation at Home

Well, again

- read through the present chapter and write down anything you did not understand.
- Also here, there are some clips for more clarification under 'Embedded resources' (check the text above/below, sometimes only part of the clip is interesting).

For checking your understanding please do the following exercises:

- ...

## 90-minute plan

1. Warm-up (x min):
  1. ....
2. Core concepts & derivations (x min):
  1. ...
3. Practice (x min): ...
4. Wrap-up (x min): Summary box; common pitfalls checklist.

## Conceptual overview

1. ...

## Core content

### Generalization of the Magnetic Field Strength

So far, only the rotational symmetric problem on a single wire was considered in formula, when the current  $I$  and the length  $s$  of a magnetic field line around it is given:

$$\begin{aligned} \quad H_{\varphi} &= \frac{I}{s} = \frac{I}{2 \cdot \pi \cdot r} \quad \Leftrightarrow \end{aligned}$$

$\oint \mathbf{H} \cdot d\mathbf{s} = I_{enc}$  applies only to the long, straight conductor

Now, this shall be generalized. For this purpose, we will look back at the electric field.

For the electric field strength  $E$  of a capacitor with two plates at a distance of  $s$  and the potential difference  $U$  holds:

$U = E \cdot s$  applies to capacitor only

In words: The potential difference is given by adding up the field strength along the path of a probe from one plate to the other.

This was extended to the voltage between two points  $1$  and  $2$ . Additionally, we know by Kirchhoff's voltage law that the voltage on a closed path is "0".

$\oint \mathbf{E} \cdot d\mathbf{s} = 0$

We can now try to look for similarities. Also for the magnetic field, the magnitude of the field strength is summed up along a path to arrive at another field-describing quantity.

Because of the similarity the so-called **magnetic potential difference  $V_m$**  between point  $1$  and  $2$  is introduced:

$V_m = \int \mathbf{H} \cdot d\mathbf{s}$  applies to rotational symmetric problems only

$V_m = \int \mathbf{H} \cdot d\mathbf{s} = \theta$

We need to take a closer look here. Any closed path in the static electric field leads to a potential difference of  $\oint \mathbf{E} \cdot d\mathbf{s} = 0$ .

BUT: closed paths in the static magnetic field leads to a magnetic potential difference which is **not mandatorily**  $0$ !  $V_m = \oint \mathbf{H} \cdot d\mathbf{s} = \theta$

Another new quantity is introduced: the **magnetic voltage  $\theta$** :

1. The magnetic voltage  $\theta$  is the magnetic potential difference on a closed path.
2. Since the magnetic voltage  $\theta$  is valid for exactly one turn along our single wire,  $\theta$  is also equal to the current through the wire:  
 $\theta = I$  applies only to the long, straight conductor
3. The magnetic potential difference can take a fraction or a multiple of one turn and is therefore **not mandatorily** equal to  $I$ .
4. The magnetic voltage is generalized in the following box.

### Notice:

The path integral of the magnetic field strength along an arbitrary closed path is equal to the free currents (= current density) through the surface enclosed by the path.

The magnetic voltage  $\theta$  (and therefore the current) is the cause of the magnetic field strength.

This leads to the **Ampere's Circuital Law**

$\oint_C \vec{H} \cdot d\vec{s} = \theta$	<p>The magnetic voltage <math>\theta</math> can be given as</p> <ul style="list-style-type: none"> <li><math>\theta = I</math> for a single conductor</li> <li><math>\theta = N I</math> for a coil</li> <li><math>\theta = \sum_n I_n</math> for multiple conductors</li> <li><math>\theta = \int_A \vec{S} \cdot d\vec{A}</math> for any spatial distribution (see <a href="#">block15</a>)</li> </ul>
---	--

**Notice:**

$\oint_C \vec{H} \cdot d\vec{s}$  and  $\int_A \vec{S} \cdot d\vec{A}$  in  $\oint_C \vec{H} \cdot d\vec{s} = \theta = \int_A \vec{S} \cdot d\vec{A}$  build a right-hand system.

1. Once the thumb of the right hand is pointing along  $\int_A \vec{S} \cdot d\vec{A}$ , the fingers of the right hand show the correct direction for  $\oint_C \vec{H} \cdot d\vec{s}$  for positive  $\vec{H}$  and  $\vec{S}$
2. Currents into the direction of the right hand's thumb count positive. Currents antiparallel to it count negative.

Fig. 1: Right hand rule



## Common pitfalls

- ...

## Exercises

## Worked examples

...

## Embedded resources

Explanation (video): ...

From:

<https://wiki.mexle.org/> - **MEXLE Wiki**

Permanent link:

[https://wiki.mexle.org/electrical\\_engineering\\_and\\_electronics\\_1/block16?rev=1763834135](https://wiki.mexle.org/electrical_engineering_and_electronics_1/block16?rev=1763834135)

Last update: **2025/11/22 18:55**

